

MULTI-AXIS MAST LIFTS

LIFT OPTIONS

- 1 Upper Rail Spacer Kits** Used to move lift out from the booth wall to provide clearance between mast and wall. Kits available with additional 4", 8" or 12" clearance. To specify kit, add 4, 8 or 12 after part number.....P/N 201-0974___
- 2 4'x4' Overspray Cover:** Used to prevent overspray from being pulled through vertical drive mechanism on side draft booths P/N 201-1024
- 3 Lower Rail Guides** (2 required per lift): Used when high solids paints are used causing build-up on lower rail. Increase lateral travel speeds and power. P/N 201-0074
- 4 Auxiliary Flex Track** with 1"x4" I.D. to carry breathing air and paint line from festooning system to basket. To specify add lift height after part number P/N 201-0075___
- 5 Safety Contact Bumper System:** Will shut down all lift motion if basket comes in contact with an obstruction. (The operator then can override the system to move away from obstruction.) P/N 202-0967
- 6 5-Gal. Paint Pot Kit:** Lift can be adapted to carry one 5-gal. paint pot. Carrier overall dimension is 16"x16" which attaches to base of lift making overall length of base 6'. Also included in kit is a paint gun holder mounted in basket capable of holding two paint guns. Two hose holders are used, one attached to mast column and one to basket rail, to run paint lines to/from paint pot to basket. All paint equipment supplied by customer. P/N 201-2350
- 7 Lower Rail Scraper Kit:** Cleans excess overspray off lower rail when paint buildup is a problem. (1 required) P/N 201-2251
- 8 Structural Kit:** Additional support for booth enclosure Consult Factory
- 9 Front Gate:** (not shown) Consult Factory
- Receiver Steps:** Required when standard steps interfere with access over product. (required with Safety Contact Bumper option)

 - Left side P/N 201-2256
 - Right side P/N 201-2255

